
Wireless AV


Connecting a Windows Device

Connect to the JoCoPublicWireless wireless network and accept the Internet Use Agreement.

Open your preferred web browser. Type in the web address shown on the bottom left of the wall display. Then, click on Start Presenting.




If the AirMedia application is installed, it will launch. Otherwise, click on the Windows button to download.





You'll need to agree to the Terms of Use. Select an option for Session Delegation.



Enter the 4-digit code found on the wall display in the bottom left corner.

